

How To Care For Your Khroma™

With regular care and maintenance, your Khroma™ will provide many years of superior performance and satisfaction. To maintain the quality of your Nightingale chair, please follow the cleaning procedures outlined here.

Mechanism

Oil moving parts if ever necessary with light machine oil.

NOTE: to prevent dripping, avoid over lubrication which may cause damage to surrounding surfaces.

Fabric or Mesh

Clean with mild detergent and water applied with a damp clean cloth or sponge. Rinse using a damp cloth. Never use hot water and avoid scrubbing. Use gentle movements.

Plastic parts

Clean with mild detergent and water. Do not use abrasives or excessive amounts of cleaner.

Frame

Powder coat frames can be cleaned by wiping with a damp cloth and any mild detergent.

* The instruction for the care and maintenance of Nightingale Products are provided to you as a service. No warranty is implied since results may vary.



User Guide Instructions

Khroma™




RECYCLABLE

How To Use and Adjust My Khroma™

Please read and understand this user guide with instructions before operating this office chair.



A. Pneumatic Height Adjustment
To lower, turn the lever up while seated. To raise, turn lever up with your weight off the seat.



B. Multi Position Tilt Lock
Turn lever up to unlock, turn down to lock.



C. Tension Knob
Turn knob clockwise to increase tension, turn counter-clockwise to decrease tension.



D. Chrome Arm Rests
with polished aluminum base. Upholstered arm pads for comfort.



E. Pillow Upholstery
A pillow upholstery technique is used with vinyl leather or leather plus to provide a wrinkled, plush appearance.



F. ENERSORB™
Conforms to your body when you sit and disperses your weight ergonomically to improve blood circulation and relieve pressure points.